

WTC 600

WTC Series Verified Balance

USER MANUAL

ITKU-24-03-01-17-EN



RADWAG BALANCES AND SCALES
ADVANCED WEIGHING TECHNOLOGIES

JANUARY 2017

CONTENTS

1. GENERAL INFORMATION	5
2. PRECAUTIONS	5
2.1. Maintenance	5
2.2. Battery	5
3. WARRANTY CONDITIONS	6
4. BALANCE DESIGN	6
4.1. Dimensions	6
4.1.1. Connection Cables - Diagrams	7
4.1.2. Connectors description	7
5. UNPACKING AND INSTALLATION	8
6. START-UP	8
6.1. Levelling.....	8
6.2. Powering the Device	8
6.3. Battery Status	9
6.4. Battery Power	9
7. MAINTENANCE ACTIVITIES	9
7.1. Cleaning ABS components	9
7.2. Cleaning stainless steel components	10
8. TEMPERATURE STABILIZATION	10
9. KEYPAD	10
10. KEYS	11
11. PROGRAM	11
12. OPERATING BALANCE MENU	12
12.1. Keypad	12
12.2. Return to the Weighing Mode	13
13. WEIGHING	13
13.1. Taring	14
13.2. Manual Tare Entering	15
13.3. Zeroing	15
13.4. Weighing for Dual Range Balances	16
13.5. Basic Weighing Unit Selection	16
13.6. Temporary Weighing Unit Selection	17
14. MAIN PARAMETERS	18
14.1. Filter Level	18
14.2. Autozero	19
14.3. Tare	19
14.4. Median Filter.....	20
15. RS 232 SETTINGS	21
15.1. Printout type	22
15.2. LO Threshold.....	23
15.3. Baud Rate.....	23
15.4. Setting Serial Communication Parameters	24
16. MISCELLANEOUS	25
16.1. Backlight.....	25
16.1.1. Backlight for Power Supply From Mains	25
16.1.2. Backlight for Power Supply From Mains or Battery	26
16.2. 'Beep' Sound	27
16.3. Automatic Shutdown.....	27
16.4. Battery Charging.....	28
17. WORKING MODES	29
17.1. Running Working Mode	30
17.2. Working Modes Accessibility	30
17.3. Selection of Modes Quantity Available For the User	31
17.4. Counting Parts of the Same Mass	31
17.5. +/- Control Against Set Reference Sample Mass.....	33
17.6. Percent Weighing Against Reference Sample Mass.....	35
17.6.1. Reference Mass Determined by Weighing.....	35
17.6.2. User-Determined Reference Mass.....	35

17.7. Autotare	36
17.8. Peak Hold	37
17.9. Totalizing	37
17.9.1. Totalizing Procedure	37
17.9.2. Last Total Sum Value Storage	38
17.9.3. Function disabling:	39
17.10. Animal Weighing	39
17.11. Tare Values Storage	41
17.11.1. Entering Tare Value to Balance Memory	41
17.11.2. Selecting Tare Value in Balance Memory	42
18. ADJUSTMENT	42
18.1. Adjustment	42
18.2. Start Mass Determination	44
19. COOPERATION WITH PRINTER	45
20. COOPERATION WITH COMPUTER	46
21. COMMUNICATION PROTOCOL	47
21.1. General Information	47
21.2. List of Commands	47
21.3. Response Format	48
21.4. Commands Overview	48
21.4.1. Zeroing	48
21.4.2. Tarring	49
21.4.3. Give Tare Value	49
21.4.4. Set tare	49
21.4.5. Send stable measurement result in basic measuring unit	50
21.4.6. Immediately send measurement result in basic measuring unit	50
21.4.7. Send stable measurement result in current measuring unit	51
21.4.8. Immediately send measurement result in current measuring unit	51
21.4.9. Switch on continuous transmission in basic measuring unit	52
21.4.10. Switch off continuous transmission in basic measuring unit	52
21.4.11. Switch on continuous transmission in current measuring unit	52
21.4.12. Switch off continuous transmission in current measuring unit	53
21.4.13. Lock balance keypad	53
21.4.14. Unlock balance keypad	53
21.4.15. Give balance serial number	53
21.4.16. Send all implemented commands	54
21.5. Manual Printout / Automatic Printout	54
21.6. Continuous Transmission	55
21.7. Printout Customization	56
22. TECHNICAL SPECIFICATIONS	56
23. TROUBLESHOOTING	57
24. ERROR MESSAGES	57
25. ADDITIONAL EQUIPMENT	58

1. GENERAL INFORMATION

WTC 600 precision balance enables fast and accurate mass measurements under laboratory conditions.

The weighing pan, made of stainless steel and equipped with anti-draft shield, is an integral part of WTC 600 balance. Backlit LCD display ensures clear measurement result. WTC balance is equipped with an internal battery (comes standard), so it does not have to be connected to the mains.

WTC 600 precision balance is equipped with RS 232 interface that enables communication between the balance and peripheral devices (e.g. printer, computer).

2. PRECAUTIONS

2.1. Maintenance

- A. Prior first use, carefully read this User Manual. Use the balance only as intended;
- B. Balance to be decommissioned, should be decommissioned in accordance with valid legal regulations.

2.2. Battery

WTC 600 precision balance is supplied by **NiMH-type** battery (*nickel-metal-hydrogen*) of **1800-2800 mAh** capacity.



In case of prolonged storage of the balance in low temperature, the battery has to be charged.



A worn out battery can be replaced only by the manufacturer or by the authorized service.



The equipment including accumulators does not belong to regular household waste. The European legislation requires electric and electronic equipment to be collected and disposed separately from other communal waste with the aim of being recycled.

Notice:


Symbols on accumulators identify harmful compounds: Pb = lead, Cd = cadmium, Hg = mercury.


3. WARRANTY CONDITIONS

- A. RADWAG feels obliged to repair or exchange all elements that appear to be faulty by production or by construction,
- B. Defining defects of unclear origin and means of their elimination can only be realized with assistance of manufacturer and user representatives,
- C. RADWAG does not bear any responsibility for defects or losses resulting from unauthorized or inadequate performing of production or service processes,
- D. Warranty does not cover:
 - mechanical defects caused by product exploitation other than intended, defects of thermal and chemical origin, defects caused by lightning, overvoltage in the power network or other random event,
 - Inappropriate cleaning.
- E. Loss of warranty takes place if:
 - a repair is carried out outside RADWAG authorized service point,
 - service claims intrusion into mechanical or electronic construction by unauthorized people,
 - the balance does not bear company protective stickers.
- F. Warranty conditions outline the warranty period for rechargeable batteries attached to the balance for 12 months.
- G. For detailed warranty conditions go to the warranty certificate.
- H. Contact with the central authorized service: (0-48) 384 88 00 ext. 106 and 107.

4. BALANCE DESIGN


4.1. Dimensions





Dimensions of WTC 600 precision balance

4.1.1. Connection Cables - Diagrams



WTC 600 connectors


- 1- 12VDC power outlet
- 2- RS232 connector

4.1.2. Connectors description

	<p>Pin2 – RxD Pin3 – TxD Pin5 – GND</p>	<p>RS 232 DB9/M connector (male)</p>
--	---	--

5. UNPACKING AND INSTALLATION

- A. Take the device out of the packaging,
- B. Place the balance on a flat and even surface. Keep it far away from any sources of heat,
- C. Install the weighing pan in accordance with the figure below:



6. START-UP

6.1. Levelling

Prior first use level the balance. To level the platform use the levelling feet and the level indicator. Keep turning the feet until the air bubble takes central position.



6.2. Powering the Device

Caution:


Balance can be connected to the mains only with a power adapter that comes standard with the particular model. Nominal power supply of the power adapter (specified on the power adapter data plate) has to be compatible to the power from the mains.

Plug the balance to the mains – connect the power adapter to the socket, next connect its connector to port located at the back of the balance housing.




Turn the balance on or off using key.

Test of the display unit takes place right after connecting the balance to the power, all the elements and pictograms are backlit for a short time. Next, the name and the program number appear, the indication gets to ZERO (displayed reading unit depends on the balance). If the indication is different than zero,



press  key.

6.3. Battery Status

An internal battery comes standard with the balance.  pictogram, displayed at the top of the display, signals battery status.

Pictogram operation	Overview
No pictogram	Battery full. Standard balance operation
Pictogram displayed continuously	Battery status low (message <bat Lo> is displayed and the balance turns off). Charge the battery immediately.
Pictogram blinks every 1s	Battery charging. Balance connected to power supplier, the battery is being charged.
Pictogram blinks every 0,5s	Battery error. Battery damaged.

6.4. Battery Power

- Simultaneously press  and  keys .
- Message **<bAtt>** is displayed for 1s. Next, battery power given in [%] is displayed for 2 s.
- Wait for the home screen to be displayed.

7. MAINTENANCE ACTIVITIES

Disassembly a weighing pan and other detachable components (the components differ depending on a balance type – see: UNPACKING AND INSTALLATION).

Caution:

Cleaning anti-draft chamber while still installed may cause damage of the measuring system.

7.1. Cleaning ABS components

To clean dry surfaces and avoid smutching use clean non-colouring cloths made of cellulose or cotton. You can use a solution of water and detergent (soap, dishwashing detergent, glass cleaner). Gently rub the cleaned surface and let it dry. Repeat cleaning process if needed.

In the case when contamination is hard to remove, e.g. adhesive, rubber, resin, polyurethane foam residues etc., you can use a special cleaning agents based on a mixture of aliphatic hydrocarbons that do not dissolve plastics. Before using the cleanser for all surfaces we recommend carrying out tests. Do not use products containing abrasive substances.

7.2. Cleaning stainless steel components

Avoid using cleansers containing any corrosive chemicals, e.g. bleach (containing chlorine). Do not use products containing abrasive substances. Always remove the dirt using microfiber cloth to avoid damage of protective coating.


In case of a daily maintenance:

1. Remove the dirt using cloth dipped in warm water.
2. For best results, add a little dishwashing detergent.

8. TEMPERATURE STABILIZATION

- For correct operation of the balance the temperature has to range $+15^{\circ}\text{C} \div +30^{\circ}\text{C}$;
- On switching on, the balance requires 30 minutes of temperature stabilization time;
- During temperature stabilization displayed information may change;
- Adjustment has to be carried out after temperature stabilization;
- Any changes of temperature and humidity during operation can cause indications errors. Errors can be corrected by carrying out user adjustment.

9. KEYPAD



WTC 600 series keypad

10. KEYS



Press to switch the balance on/off – keep pressing for about 1 s



Function key: press to select respective operation mode.



Press to send the weighing result to a printer or a computer.



Press to zero the balance



Press to tare the balance

Caution:



On pressing (Esc F) and (Printer/Computer) keys balance menu is displayed and keys' functions change. For detailed overview of keys' functions go further down this user manual.

11. PROGRAM

Main menu is divided into function groups. Function group is a group of interrelated parameters.

Parameter No.	Name	Options	Overview
P1.	rEAd	-	Balance parameters
1.1.	FIL	1, 2, 3	Filter
1.2.	Auto	YES, no	Autozero
1.3.	tare	no, AtAr, tArF	Tare
1.4.	FnnD	YES, no	Median Filter
P2.	Prnt		RS232 parameters settings
2.1.	Pr_n	StAb, noStAb, rEPL, CntA, Cntb	Printout type
2.2.	S_Lo		LO Threshold
2.3.	bAud	2400, 4800, 9600, 19200, 38400	RS232 baud rate
2.4.	S_rS	7d2SnP, 7d1SEP, 7d1SoP, 8d1SnP, 8d2SnP, 8d1SEP, 8d1SoP	Serial communication parameters
P3.	Unit		Units
		g, kg, N, ct, lb	Basic weighing unit selection
P4.	Func		Working modes

	4.1.	FFun	ALL, Funi, PcS, HiLo, AtAr, PrcA, Prcb, toP, Add, AnLS, tArE	Selection of modes quantity available for the user
	4.2.	Funi	YES, no	<Funi> mode accessibility
	4.3.	PCS	YES, no	<PcS> mode accessibility
	4.4.	HiLo	YES, no	< HiLo> mode accessibility
	4.5.	PrcA	YES, no	< PrcA> mode accessibility
	4.6.	Prcb	YES, no	< Prcb> mode accessibility
	4.7.	AtAr	YES, no	< AtAr> mode accessibility
	4.8.	toP	YES, no	< toP > mode accessibility
	4.9.	Add	YES, no	< Add> mode accessibility
	4.A.	AnLS	YES, no	<AnLS> mode accessibility
	4.b.	tArE	YES, no	<tArE> mode accessibility
P5.		Misc		Miscellaneous
	5.1.	bL	no, YES, Auto	Backlight for power supply from mains
	5.2.	bLbA	no, 10, 20, 30, 40, 50, 60, 70, 80, 90, 100	Backlight for power supply from battery
	5.3.	bEEP	YES, no	Key sound
	5.4.	t1	no, YES, Auto	Time-defined finish mode
	5.5.	CHr6	YES, no	Battery charging function
P6.		CAL		Adjustment
	6.1.	St_u	-	Start mass determination
	6.2.	uCAL	-	Adjustment process

12. OPERATING BALANCE MENU

Use keypad to navigate in menu.

12.1. Keypad



Press to enter 'Main Menu'



Press to enter tare value manually

Press to edit parameter value and to change it by 1 digit up

Press to move the menu up



Press to check battery status






Press to switch between gross / net value






Press to swap between particular menu/submenu parameter

Press to change current parameter value


-  Press to enter particular submenu
Press to select parameter that is to be modified
-  Press to confirm introduced modifications
-  Press to leave, parameter remains unmodified
Press to move one menu level up

12.2. Return to the Weighing Mode


Introduced modifications are permanently recorded into balance memory upon returning to the weighing operation after carrying out saving procedure.

Press  key repeatedly, keep pressing until message **<SAuE?>** is displayed. Upon noticing the query press:  - to confirm introduced modifications, or  - to resign from introducing the modifications. Now the balance proceeds to weighing.


13. WEIGHING

Load the weighing pan. You can read weighing result when  pictogram is displayed. To assure long-term operation and correct mass measurements follow the rules presented below:


- Load the weighing pan steadily avoiding shocks:




- Place weighed loads centrally on the weighing pan (eccentricity errors are specified by PN-EN 45501 standard, points 3.5 and 3.6.2.):



- Do not load the pan with concentrated force:




- Avoid side loading, in particular side shocks:



13.1. Taring

To determine net weight, put the packaging on the weighing pan. On stabilizing, press key (indication changes to zero, **Net** pictogram is displayed in the left upper corner):




On loading the weighing pan net weight is displayed. You can tare repeatedly within the whole measuring range. While using tare function remember not to exceed the maximum measuring range of the balance. On unloading the weighing pan, the sum of tared masses with minus sign is displayed.




Caution:

*Taring cannot be performed when the displayed value is negative or equal zero. In such case message **<Err3>** is displayed and short signal is emitted.*

13.2. Manual Tare Entering

- Simultaneously press  and  keys.






- Using  and  keys set **tare value**,
- Press  key,
- Balance returns to weighing mode. Tare value with '-' sign is displayed.
- Tare can be entered at any moment during the weighing process.

Caution:

Tare cannot be entered manually when tare value is already implemented to balance's memory. In such case message <Err3> is displayed and a short signal is emitted.

13.3. Zeroing

To zero mass indication press  key. Zero value and following pictograms  and  are displayed.


Zeroing enables determining new precise zero point. Zeroing is possible only when the indication is stable.

Caution:

Indication can be zeroed only within $\pm 2\%$ range of maximum capacity. If the zeroed value is greater than $\pm 2\%$ of the maximum capacity, message <Err2> is displayed and short signal is emitted.

13.4. Weighing for Dual Range Balances

Switching from weighing with the accuracy of the **I weighing range** to weighing with the accuracy of the **II weighing range** takes place automatically on exceeding Max of **I weighing range**. On switching to weighing with the accuracy of the II weighing range, ± 2 symbol is displayed on the left. On unloading the weighing pan indication zeroes. Weighing is carried out with **II range** accuracy until the indication is zeroed.




Switching from weighing with the accuracy of the **II weighing range** to weighing with the accuracy of the **I weighing range** takes place automatically on unloading the weighing pan and returning to AUTOZERO – (symbol ± 0 is displayed). II weighing range pictogram is blanked and the balance switches back to the **I weighing range**.

13.5. Basic Weighing Unit Selection

You can set the start unit.

Procedure:

- Enter <P3.Unit> submenu.



- Press ± 0 key to view available units:




Options:

- A. When [kg] is the main unit, then you can select the following units:[kg, lb, N]; [*lb*] *unavailable for verified balances,*
- B. When [g] is the main unit, then you can select the following units:[g, ct, lb]; [*lb*] *unavailable for verified balances,*



- On selecting basic unit, press key to confirm. Return to home screen:



- Return to the weighing mode saving introduced modifications.

Caution:


The balance turns on with basic start unit selected.

13.6. Temporary Weighing Unit Selection

Function enables selecting mass indication unit. Temporary unit remains active until it is changed or the balance is turned off.

Procedure:

- Press  key, next:



- On confirmation the balance proceeds to weighing with selected unit.

Options:

- A. When [kg] is the main unit, then you can select the following units:[kg, lb, N]; *[lb] unavailable for verified balances,*
- B. When [g] is the main unit, then you can select the following units:[g, ct, lb]; *[lb] unavailable for verified balances,*


14. MAIN PARAMETERS

You can adjust the balance to ambient conditions (filter level) or to your own needs (autozero, tare value). The parameters are to be found in **<P1.rEAd>** submenu.

14.1. Filter Level

Procedure:

- Enter **<P1.rEAd>** submenu.



1 - 4 - filter setting in accordance with the ambient conditions

- Return to the weighing mode saving introduced modifications.

Caution:

The higher filter level, the longer the indication takes to stabilise.


14.2. Autozero

The software features an autozero function (Auto) ensuring precise mass indication. This function automatically controls and corrects zero indication.

There are, however, some cases when this function can be a disturbing factor for the measuring process; e.g. very slow placing of a load on the weighing pan (load adding). In such case, it is recommended to disable the function.

Procedure:

- Enter <P1.rEAd> submenu.




- Return to the weighing mode saving introduced modifications.


14.3. Tare

Function enables setting appropriate parameters related with taring.

Procedure:

- Enter <P1.rEAd> submenu.



- tare AtAr** - **automatic tare** - saved after the power supply is disconnected;
- tare no** - **basic tare mode** (taring using  key);
- tare tArF** - **tare storage** - last tare value is stored in balance's memory. Tare value is automatically displayed on restarting the balance.


- Return to the weighing mode saving introduced modifications.

14.4. Median Filter

Median filter enables eliminating short impulse interferences (e.g. mechanical shocks).

Procedure:

- Enter <P1.rEAd> submenu.



FnnD **no** - median filter disabled
FnnD **YES** - median filter enabled

- Return to the weighing mode saving introduced modifications.


15. RS 232 SETTINGS

External devices connected to RS 232C have to be supplied from the same mains with common electric shock protection. It prevents from appearing potential difference between neutral conductors of the two devices. This notice does not apply to the devices that do not use neutral conductors.

Transmission parameters:


- Baud rate - 2400 - 38400 bit/s
- Data bits - 7, 8
- Stop bits - 1, 2
- Parity - no, even, odd

The indication can be sent by serial port to peripheral device in one of the following ways:

- **Manually** - on pressing  key,
- **Automatically** - on indication stabilization,
- **Continuously**- on function activation or on sending control command,

- **On external request** - see description in point: COMMUNICATION PROTOCOL.

The indication can be sent by serial port to peripheral device in one of the following ways:


- **stable** - information is send on indication stabilization
- **unstable** – on pressing  key the indication is send to peripheral device and „?“ pictogram is printed on a printout before weighing result.

15.1. Printout type

Parameter enables selecting printout type.

Procedure:

- Enter <P2.Prnt> submenu.



- | | | |
|-------------|---------------|--|
| Pr_n | noStAb | - Unstable weighing results printout.
Function unavailable for non-verified balances. |
| Pr_n | StAb | - Stable weighing results printout. |
| Pr_n | rEPL | - Automatic operation |
| Pr_n | CntA | - Continuous transmission in basic unit. |
| Pr_n | Cntb | - Continuous transmission in current unit. |

- Return to the weighing mode saving introduced modifications.

15.2. LO Threshold

<2.2.S_Lo> parameter is connected with automatic operation.


Next, taring is saved when mass indication is below **LO threshold** gross value.

For automatic operation enabled, the indication is send to computer or printer when mass indication is below net value of **Lo threshold**.

Animal weighing starts when animal mass exceeds gross value of **Lo threshold**.

Procedure:

- Enter <P2.Prnt> submenu.




- Return to the weighing mode saving introduced modifications.

15.3. Baud Rate

Procedure:


- Enter <P2.Prnt> submenu.



- Return to the weighing mode saving introduced modifications.

15.4. Setting Serial Communication Parameters

- Enter `<P2.Prnt>` submenu.



7d2SnP - 7 data bits; 2 stop bits, no parity

7d15EP - 7 data bits; 1 stop bit, EVEN parity

- 7d1SoP** - 7 data bits; 1 stop bit, ODD parity
- 8d1SnP** - 8 data bits; 1 stop bits, no parity
- 8d2SnP** - 8 data bits; 2 stop bits, no parity
- 8d1SEP** - 8 data bits; 1 stop bit, EVEN parity
- 8d1SoP** - 8 data bits; 1 stop bit, ODD parity

- Return to the weighing mode saving introduced modifications.

16. MISCELLANEOUS

You can set the following parameters: backlight, 'beep' signal, automatic shutdown. The parameters are to be found in **<P5.Misc>** submenu.

16.1. Backlight


The balance automatically selects type of backlight on recognising power supply type (mains, batteries):

- **bL** – mains
- **blbA** – battery

16.1.1. Backlight for Power Supply From Mains

Procedure:

- Enter **<P5.Misc>** submenu.



- bL no** - backlight disabled
- bL YES** - backlight enabled
- bL Auto** - backlight automatically disabled when indication does not change over 10s

- Return to the weighing mode saving introduced modifications.

Caution:


For **bL=Auto** setting, the backlight is automatically disabled when the indication remains unchanged for 10s. Backlight is automatically enabled on displayed indication change.

16.1.2. Backlight for Power Supply From Mains or Battery

You can change display brightness: 0% - backlight disabled, 100% - maximum brightness. For lower intensity of the brightness, battery operation time increases. The function is set to **Auto** value when the brightness is set.

Procedure:

- Enter <P5.Misc> submenu.



- Return to the weighing mode saving introduced modifications.


Caution:

Using backlight shortens battery operation time.

16.2. 'Beep' Sound

Procedure:

- Enter <P5.Misc> submenu.



bEEP **no** - 'beep' sound disabled
bEEP **YES** - 'beep' sound enabled

- Return to the weighing mode saving introduced modifications.

16.3. Automatic Shutdown

The function enables saving battery power. When **t1** parameter is active, the balance is automatically shut down within 5 minutes when there was no weighing carried out (indication did not change).


Function Operation According to Power Supply Type

Function setting	Function operation	
	Mains	Battery
t1 = 0	Disabled	Disabled
t1 = YES	Enabled	Enabled
t1 = Auto *	Disabled	Enabled

* function is enabled or disabled automatically depending on power supply type.

Procedure:

- Enter **<P5.Misc>** submenu.




- Return to the weighing mode saving introduced modifications.



16.4. Battery Charging

Option allows to enable or disable batteries charging.

a) **<5.5.Chr6>** parameter set to **<no>** value:

-  pictogram is not displayed, charging disabled.
- Message **<bAtt>** is displayed on switching on the balance.

b) **<5.5.Chr6>** parameter set to **<YES>** value:


-  pictogram blinks slowly during charging (2s interval), charging enabled.
- Message **<nImh>** is displayed on balance turning on.
- When there is no battery (batteries) or the battery is broken  pictogram blinks quickly 0.5s interval).

Caution:

Balances are equipped with **NiMH-type** batteries of **R6 (AA)** size and power supply.

Procedure:

- Enter **<P5.Misc>** submenu.



- CHr6 YES** - function enabled (signalling enabled)
- CHr6 no** - function disabled (signalling disabled)




- Return to the weighing mode saving introduced modifications.

17. WORKING MODES

The balance features the following working modes:

- Weighing,
- Parts counting,
- +/- control
- Percent weighing
- Autotare,
- Peak hold
- Totalising,
- Animal weighing
- Tare values storage


17.1. Running Working Mode

- In home screen press  key. Name of first available working mode is displayed.
- Press  key to view available working modes.
- Press  key to enter a working mode.

Caution:


The balance is restarted with the weighing mode activated!!!

17.2. Working Modes Accessibility

In **<4.2.Func>** parameter you can declare functions available on pressing  key.

Procedure:

- Enter **<P4.Func>** submenu.




no - mode unavailable
YES - mode available

Caution:

To make other modes available follow the abovementioned procedure.


- Return to the weighing mode saving introduced modifications.

17.3. Selection of Modes Quantity Available For the User

Function enables selecting whether on pressing  key will be available all modes (option <ALL>) or just one selected and used by an operator.

Procedure:

- Enter <P4.Func> submenu.



- Return to the weighing mode saving introduced modifications.



17.4. Counting Parts of the Same Mass


Standard balance is equipped with option of counting parts of the same mass. When you use a container to carry out parts counting, first tare it.

Caution:

- 1. Parts counting does not work with other functions of the balance.
- 2. Parts counting function is not active on balance restart.






Procedure:


- Enter **<PcS>** submenu.
- Blinking quantity of parts is displayed. Press  key to select parts quantity. Press  key to confirm.





- If **<LAST>** value is selected, last determined mass of a single part is displayed for 3s. Balance automatically returns to **Parts counting** mode and sets value displayed before.
- If **<FrEE>** value is selected, the following window is displayed:



- Press  and  keys to enter parts quantity, where:  - selecting the digit,  - selecting digit's value,
- Press  key to confirm.
- Message **<LoAd>** is displayed. Next, the following window is displayed:




- If the parts are to be weighed in a container, first put it onto weighing pan and then tare it. Next, load the weighing pan with declared amount of parts. When the indication is stable (pictogram  is displayed) confirm its mass:



- Mass of a single part is measured automatically. **Parts counting** mode and parts quantity [pcs] are displayed.

Caution:



1. If you press  key when the weighing pan is not loaded with parts, error message **-Lo-** is displayed for a few seconds and the balance automatically returns to weighing mode.
2. In order to obtain reliable results, load the weighing pan with parts which mass value of a single part is greater than 5 reading units.
3. If mass of a single part is smaller than reading unit, message **<Err5>** is displayed and short signal is emitted. Balance returns to the weighing mode.

Function disabling:


Press  key twice.


17.5. +/- Control Against Set Reference Sample Mass


+/- control mode enables entering checkweighing thresholds values (**Min**, **Max**).


Procedure:


- Enter **<HiLo>** submenu,
- Window for setting (**Min**) threshold value is displayed:



- Press  key to confirm. Window for setting (**Max**) threshold value is displayed automatically:



- Press  key to confirm. Weighing mode home screen is displayed automatically with saved thresholds values.
- The following dependencies occur during setting threshold values:



Caution:

If value of entered low threshold (Min) is greater than high threshold value (Max), error message is displayed and the balance returns to the weighing mode.

Function disabling:

Press  key twice.


17.6. Percent Weighing Against Reference Sample Mass



Percent weighing mode enables comparison of measured sample with reference mass. The result is expressed in [%]. Reference mass can be determined by weighing (**PrcA** parameter) or entered to balance's memory (**PrcB** parameter).

17.6.1. Reference Mass Determined by Weighing

Procedure:

- Enter **<PrcA>** submenu,
- Message **<LoAd>** is displayed. Next, the following window is displayed:



- Load the weighing pan with reference mass. When the indication is stable ( pictogram is displayed) press  key to confirm the mass.
- Display indicates **100,000%** value,
- Difference between values of loaded mass and reference mass is displayed in [%].

Function disabling:






Press  key twice.

17.6.2. User-Determined Reference Mass

Procedure:

- Enter **<Prcb>** submenu,
- The following window is displayed:



- Press  and  keys to enter **reference mass value**,
where:  - selecting the digit,  - selecting digit's value,
- Press  key to confirm.
- Display indicates **0,000%** value,
- Difference between values of loaded mass and reference mass is displayed in [%].

Function disabling:

Press  key twice.

17.7. Autotare

Autotare enables quick net weight determination of weighed objects when tare value is different for next loads. When autotare is enabled, operation is as follows:

- For empty weighing pan press zeroing key,
- Load the weighing pan with the packaging,
- On indication stabilization, packaging mass is **automatically tared (Net pictogram is displayed in the upper part of the display)**,
- Insert object into packaging,
- Object net weight is displayed,
- Unload the weighing pan (object and packaging),
- Indication zeroes,
- Load the weighing pan with another object, on indication stabilization, packaging mass is automatically tared (**Net** pictogram is displayed in the upper part of the display),
- Insert next object into packaging.

Function disabling:


Press  key twice.

17.8. Peak Hold

Procedure:

- Enter **<toP>** submenu,
- On selecting peak hold option, pictogram **Max** is displayed in the upper part of the display.



- Load the weighing pan with variable force, maximum value of the force is snapped and displayed.
- Unload the weighing pan.
- Prior next weighing press  key.


Function disabling:

Press  key twice.

17.9. Totalizing


Totalizing mode enables mass totalizing of weighed ingredients and printing totalizing report on a printer connected to the balance.

17.9.1. Totalizing Procedure

- Enter **<Add>** submenu,
- On selecting **<Add>** option, pictogram „**P**” is displayed in the left part of the display.
- Load the weighing pan with first object. If the objects are to be weighed in a container, first put it onto weighing pan and then tare it. Next, load the weighing pan with the object. When the indication is stable (pictogram 


is displayed) confirm its mass: 


- Weighings sum and '▲' pictogram are displayed in the right upper corner of the display and the weighing result is printed out using printer connected to the balance.




- Unload the weighing pan. **ZERO** indication and „P” pictogram are displayed,
- Load the weighing pan with next object.



- On indication stabilization, press  key. Total sum of the first and the second weighing and pictogram „▲” are displayed in the right upper part of the display. The weighing result is printed out using printer connected to the balance.





- Press  key to finish the process (with loaded or unloaded weighing pan). Total sum of all saved measurements is printed out using printer connected to the balance:

(1) 1.912 kg

(2) 1.912 kg





TOTAL: 3.824 kg

- When you press  key with loaded weighing pan, message **<unLoAd>** is displayed. Unload the weighing pan, **ZERO** indication and „P” pictogram are displayed. The balance is ready for next totalizing process.
- When you press  key with unloaded weighing pan, „P” pictogram is displayed on the left. The balance is ready for next totalizing process.

17.9.2. Last Total Sum Value Storage

On aborting totalizing (balance disabling, power loss etc.) you can restart the process with last total sum calculated. In order to restart totalizing:





- Enter **<Add>** submenu,
- Value of a total sum saved before balance restart is displayed.

- In order to continue totalizing process press  key. **ZERO** indication and „P” pictogram are displayed. The balance is ready for next totalizing process.
- In order to finish totalizing process, press ,  or  key. „P” pictogram is displayed in the left part of the display. The balance is ready for next totalizing process.

17.9.3. Function disabling:


- Press  key, the following window is displayed:

Print ?

- Prior leaving **<Add>** option, you can print out mass values of single loads and total sum of the totalizing process using printer connected to the balance (press  key to print and  key to cancel printing).
- Message **<ESC?>** is displayed,
- In order to return to the weighing mode, press  key,
- In order to return to the totalizing mode, press  key.

Caution:


*In case of exceeding display range of totalized mass on balance's display, message **<5-FULL>** is displayed. In such case, unload the weighing pan and*


press  key to finish totalizing process and print out total sum using printer connected to the balance. Load the weighing pan with smaller mass that does not exceed display range of totalized mass.

17.10. Animal Weighing

Procedure:


- Enter **<AnLS>** submenu,
- For **1s** message **<tinnE>** is displayed. Next, window for setting duration (in seconds) of animal weighing is displayed:




- Press  key to confirm. The following window is displayed:



- Load the weighing pan with an animal,
- On exceeding set value of **-LO-** parameter, animal weighing starts. < - - - - - - - -> pictogram signalling process progress is displayed.
- On process completion mass value of an animal is snapped and displayed together with **OK** pictogram in the upper part of the display.



- Press  key to restart animal weighing.
- On process completion and unloading the weighing platform, the following window is displayed:



Function disabling:

Press  key.


17.11. Tare Values Storage


You can enter 9 tare values to balance memory.

17.11.1. Entering Tare Value to Balance Memory


Procedure:


- Enter <tArE> submenu,
- Window with the name of first tare <tArE 0> is displayed in tare database


(press  key to select other record):



- On selecting the tare, press  key. The following window is displayed:



- Enter set **tare value** by pressing  key,
- The following window is displayed:





Function disabling:


Press  key.

17.11.2. Selecting Tare Value in Balance Memory

- Enter <tArE> submenu,
- Window with the name of first tare <tArE 0> is displayed in tare database

(press  key to select other record):



- Press  key to use selected tare,
- The value of used tare with minus sign and **Net** pictogram are displayed in the left upper part of the display:



Caution:

Entered tare value is not saved on balance restart.

18. ADJUSTMENT


option available for non-verified balances exclusively

In order to ensure the highest weighing accuracy, it is recommended to periodically introduce a corrective factor of indications to balance memory, the said factor must be referred to the reference mass. Adjustment has to be carried out prior first weighing or if the ambient temperature has changed dynamically. Prior adjustment unload the weighing pan.


18.1. Adjustment

Procedure:

- Enter <P6.CAL> submenu. Next:




- The following messages are displayed:



- During this time, determination of balance start mass is carried out. On process completion, mass of an adjustment weight is displayed (e.g. **3.000kg**).
- Load the weighing pan with weight of displayed value,
- Adjustment process starts automatically on loading the weighing pan with the weight. The following message is displayed:




- Adjustment process completion is signalled by the following message:



- Unload the weighing pan. Message **<donE>** is displayed for 1 s. Balance returns to displaying adjustment submenu name:

done


6.2. uCAL

- Adjustment process can be aborted at any time. To do that, press  key. The following message is displayed:

Abort

Caution:

1. It is crucial to carry out balance adjustment with unloaded weighing pan!
2. If adjustment process takes more than 15 seconds then **<Err8>** error

message is displayed and short sound signal is emitted. Press  key and carry out adjustment procedure again. Remember to maintain stable ambient conditions!


- Return to the weighing mode saving introduced modifications.

18.2. Start Mass Determination

If the balance does not require adjustment or you do not have suitable amount of weights, you can determine balance start mass.

Procedure:

- Enter **<P6.CAL>** submenu. Next:




- The following messages are displayed:

StCAL

done


- On completion of start mass determination, the balance returns to displaying name of the parameter:

6.1. St_u

- Start mass determination can be aborted at any moment. To do that, press  key. The following message is displayed:


Abort

Caution:

If start mass determination takes more than 15 seconds then **<Err8>** error message is displayed and short sound signal is emitted. Press  key and carry out adjustment procedure again. Remember to maintain stable ambient conditions!


- Return to the weighing mode saving introduced modifications.

19. COOPERATION WITH PRINTER

Press  key to send current mass value with mass units to the printer.

Depending on **STAB** parameter setting, you can print current or stable value. Depending on **REPL** parameter setting, printout can be automatic or manual. The following printer can cooperate with the balance:


Connection cable - diagram:




Balance - printer cable (EPSON)

20. COOPERATION WITH COMPUTER

You can send the results to the computer:

- manually
 - continuously
 - automatically
 - on computer request
- on pressing  key
 - on function activation or on sending control command
 - on indication stabilization
 - on sending control command

Connection cable - diagram:



Balance - computer cable

The balance enables cooperation with „**SCALE EDITOR**” computer software. Balance window in the software comprises the same crucial information on weighing as balance’s display. The software enables uncomplicated way of balance configuration, e.g. printouts customization, main parameters and RS232 parameters edition. For detailed description of balance-software cooperation go to „**Help...**” bookmark.

21. COMMUNICATION PROTOCOL

21.1. General Information

- A. A character based communication protocol balance-terminal is designed for establishing communication between a RADWAG balance and a peripheral device via RS-232C interface.
- B. The protocol consists of commands sent from a peripheral device to the balance and responses from the balance.
- C. Responses are sent from the balance each time a command is received.
- D. Commands, forming the communication protocol, enable obtaining data on balance status and facilitate influencing balance operation, e.g.: acquiring measurement results from the balance, monitoring the display, etc.

21.2. List of Commands

Command	Command overview
Z	Zero balance
T	Tare balance
OT	Give tare value
UT	Set tare
S	Send stable measurement result in basic measuring unit
SI	Immediately send measurement result in basic measuring unit
SU	Send stable measurement result in current measuring unit
SUI	Immediately send measurement result in current measuring unit
C1	Switch on continuous transmission in basic measuring unit
C0	Switch off continuous transmission in basic measuring unit
CU1	Switch on continuous transmission in current measuring unit
CU0	Switch off continuous transmission in current measuring unit
K1	Lock balance keypad

K0	Unlock balance keypad
NB	Give balance serial number
PC	Send all implemented commands

Caution:

1. Each command must end with CR LF characters;
2. Wait before sending another command until the former answer has been received, otherwise the answers may be lost.

21.3. Response Format

On receipt of a command, the indicator responds as follows:

XX_A CR LF	command understood and in progress
XX_D CR LF	command carried out (appears only after the XX_A command)
XX_I CR LF	command understood but not accessible at this moment
XX_^ CR LF	command understood but max threshold is exceeded
XX_v CR LF	command understood but min threshold is exceeded
ES_CR LF	command not recognised
XX_E CR LF	time limit exceeded while waiting for stable measurement result (time limit is a characteristic balance parameter)

XX - name of a sent command

_ - space

21.4. Commands Overview

21.4.1. Zeroing

Format: **Z CR LF**

Response options:

Z_A CR LF	command understood and in progress
Z_D CR LF	command carried out
Z_A CR LF	command understood and in progress
Z_^ CR LF	command understood but zeroing range is exceeded
Z_A CR LF	command understood and in progress
Z_E CR LF	time limit exceeded while waiting for stable measurement result
Z_I CR LF	command understood but not accessible at this moment

21.4.2. Tarring

Format: **T CR LF**

Response options:

T_A CR LF	command understood and in progress
T_D CR LF	command carried out
T_A CR LF	command understood and in progress
T_v CR LF	command understood but taring range is exceeded
T_A CR LF	command understood and in progress
T_E CR LF	time limit exceeded while waiting for stable measurement result
T_I CR LF	command understood but not accessible at this moment

21.4.3. Give Tare Value

Format: **OT CR LF**

Response: **OT_TARA CR LF** - command carried out

Response format:

1	2	3	4	5-6	7-15	16	17	18	19	20	21
T	T	space	stability marker	space	tare	space	unit			CR	LF

Tare - 9 characters, right justification

Unit - 3 characters, left justification

21.4.4. Set tare

Format: **UT_TARA CR LF**, where **TARA** - tare value

Response options:

UT_OK CR LF	command carried out
UT_I CR LF	command understood but not accessible at this moment
ES CR LF	command not recognised (tare format incorrect)

Caution:

Use dot in tare format as decimal point.

21.4.5. Send stable measurement result in basic measuring unit

Format: **S CR LF**

Response options:

S_A CR LF S_E CR LF	command understood and in progress time limit exceeded while waiting for stable measurement result
S_I CR LF	command understood but not accessible at this moment
S_A CR LF MASS FRAME	command understood and in progress response: mass value in basic measuring unit

Response format:

1	2-3	4	5	6	7-15	16	17	18	19	20	21
S	space	stability marker	space	character	mass	space	unit			CR	LF

Example:

S CR LF – command sent from a computer

S _ A CR LF – command understood and in progress

S _ _ _ _ - _ _ _ _ _ 8 . 5 _ g _ _ CR LF - command carried out,
response: mass value in basic measuring unit.

21.4.6. Immediately send measurement result in basic measuring unit

Format: **SI CR LF**

Response options:

SI_I CR LF	command understood but not accessible at this moment
MASS FRAME	immediate response: mass value in basic measuring unit

Response format:

1	2	3	4	5	6	7-15	16	17	18	19	20	21
S	I	space	stability marker	space	character	mass	space	unit			CR	LF

Example:

SI_I CR LF – command sent from a computer

SI _ ? _ _ _ _ _ 1 8 . 5 _ k g _ CR LF - command carried out,
immediate response: mass value in basic measuring unit

21.4.7. Send stable measurement result in current measuring unit

Format: **SU CR LF**

Response options:

SU_A CR LF SU_E CR LF	command understood and in progress time limit exceeded while waiting for stable measurement result
SU_I CR LF	command understood but not accessible at this moment
SU_A CR LF MASS FRAME	command understood and in progress response: mass value in current measuring unit

Response format:

1	2	3	4	5	6	7-15	16	17	18	19	20	21
S	U	space	stability marker	space	character	mass	space	unit			CR	LF

Example:

S U CR LF – command sent from a computer

S U _ A CR LF - command understood and in progress

S U _ _ _ - _ _ 1 7 2 . 1 3 5 _ N _ _ CR LF - command carried out,
response: mass value in current measuring unit.

21.4.8. Immediately send measurement result in current measuring unit

Format: **SUI CR LF**

Response options:

SUI CR LF	command understood but not accessible at this moment
MASS FRAME	immediate response: mass value in current measuring unit

Response format:

1	2	3	4	5	6	7-15	16	17	18	19	20	21
S	U	I	stability marker	space	character	mass	space	unit			CR	LF

Example:

S U I CR LF – command sent from a computer

S U I ? _ - _ _ _ 5 8 . 2 3 7 _ k g _ CR LF - command carried out,
immediate response: mass value in current measuring unit

21.4.9. Switch on continuous transmission in basic measuring unit

Format: **C1 CR LF**

Response options:

C1_I CR LF	command understood but not accessible at this moment
C1_A CR LF MASS FRAME	command understood and in progress response: mass value in basic measuring unit

Response format:

1	2	3	4	5	6	7-15	16	17	18	19	20	21
S	I	space	stability marker	space	character	mass	space	unit			CR	LF

21.4.10. Switch off continuous transmission in basic measuring unit

Format: **C0 CR LF**

Response options:

C0_I CR LF	command understood but not accessible at this moment
C0_A CR LF	command understood and carried out

21.4.11. Switch on continuous transmission in current measuring unit

Format: **CU1 CR LF**

Response options:

CU1_I CR LF	command understood but not accessible at this moment
CU1_A CR LF MASS FRAME	command understood and in progress response: mass value in current measuring unit

Response format:

1	2	3	4	5	6	7-15	16	17	18	19	20	21
S	U	I	stability marker	space	character	mass	space	unit			CR	LF

21.4.12. Switch off continuous transmission in current measuring unit

Format: **CU0 CR LF**

Response options:

CU0_I CR LF	command understood but not accessible at this moment
CU0_A CR LF	command understood and carried out

21.4.13. Lock balance keypad

Format: **K1 CR LF**

Response options:

K1_I CR LF	command understood but not accessible at this moment
K1_OK CR LF	command carried out

Caution:

Command is not saved on balance restart.

21.4.14. Unlock balance keypad

Format: **K0 CR LF**

Response: **K0_OK CR LF** - command carried out

21.4.15. Give balance serial number

Format: **NB CR LF**

Response options:

NB_A "Nr fabryczny" CR LF	command understood, response: serial number
NB_I CR LF	command understood but not accessible at this moment

"nr fabryczny" – serial number of the device. Inserted in between inverted commas.

Example:

NB CR LF – command sent from a computer

NB_A "123456" CR LF – balance serial number - 123456


21.4.16. Send all implemented commands

Format: **PC CR LF**

Response: **PC_- >_Z,T,OT,UT,S,SI,SU,SUI,C1,C0,CU1,CU0,K1,K0,NB,PC** - command carried out, all implemented commands have been sent.

21.5. Manual Printout / Automatic Printout

It is possible to generate printouts either manually or automatically.

- Manual printout is generated for stable weighing result. Load the platform, wait for a stable result and press  key.
- Automatic printout is generated for stable weighing result. Load the platform, wait for a stable result. No key needs to be pressed.

Caution:

For verified balance option of temporary weighing results printout is disabled.

Format:

1	2	3	4 -12	13	14	15	16	17	18
stability marker	space	character	mass	space	unit			CR	LF

- Stability marker** [space] if measurement result stable
[?] if measurement result unstable
[^] if high limit is out of range
[v] if low limit is out of range
- character** [space] for positive values
[-] for negative values
- Mass** 9 characters with decimal point, right justification
- unit** 3 characters, left justification
- Command** 3 characters, left justification

Example 1:

____ 1 8 3 2 . 0 _ g _ _ **CR LF** - printout generated upon pressing ENTER/PRINT key.

Example 2:

? _ - ____ 2 . 2 3 7 _ l b _ **CR LF** - printout generated upon pressing ENTER/PRINT key.

Example 3:

^ _ _ _ _ _ 0 . 0 0 0 _ k g _ CR LF - printout generated upon pressing ENTER/PRINT key.

21.6. Continuous Transmission

For continuous transmission the balance provides option of mass measurement printout in basic unit and in additional unit. The mode can be activated with command sent via interface, or by setting respective parameter values.

Format is valid for <P2.Prnt> parameter set to **CntA** value:

1	2	3	4	5	6	7-15	16	17	18	19	20	21
S	I	space	stability marker	space	character	mass	space	unit			CR	LF

Stability marker [space] if measurement result stable
[?] if measurement result unstable
[^] if high limit is out of range
[v] if low limit is out of range

character [space] for positive values
[-] for negative values

Mass 9 characters with decimal point, right justification

unit 3 characters, left justification

Command 3 characters, left justification

Format valid for <P2.Prnt> parameter set to **Cntb** value:

1	2	3	4	5	6	7-15	16	17	18	19	20	21
S	U	I	character marker	space	character	Mass	space	unit			CR	LF

Stability marker [space] if measurement result stable
[?] if measurement result unstable
[^] if high limit is out of range
[v] if low limit is out of range

character [space] for positive values
[-] for negative values

Mass 9 characters with decimal point, right justification

unit 3 characters, left justification

Command 3 characters, left justification

21.7. Printout Customization

GENERAL INFORMATION

Standard printout content can be customized. Using **SCALES EDITOR**, freeware software it is possible to specify which data is to be printed, which not. In order to download the software visit RADWAG website: <http://www.radwag.com>. In order to download the software, visit RADWAG website:

<http://www.radwag.pl>

22. TECHNICAL SPECIFICATIONS

Scales model:	WTC 600
Max capacity	600g
Min capacity	0.5g
Readability [d]	0.01g
Verification unit [e]	0.1g
Tare range	-600g
Repeatability	0.01g
Linearity	±0.02 g
Stabilization time	2 s
OIML class	II
Weighing pan dimensions	128x128mm
IP rating	IP 43
Operating temperature	+15°C ÷ +30°C
Power supply	100 ÷ 240 V AC, 50 ÷ 60 Hz / 12 V DC + battery
Battery operating time	33h (average time)
Display	LCD with backlight
RS232	x1
Net/gross weight	1.3 / 2kg
Packaging dimensions	330x230x140mm

23. TROUBLESHOOTING

Problem	Cause	Solution
The balance does not switch on	Battery (batteries) discharged,	Connect it to the mains, charge the battery (batteries)
	No batteries (batteries not installed or installed incorrectly)	Check if batteries are installed correctly (polarization)
The balance switches off automatically	't1' parameter set to 'YES' value (the balance switches off automatically)	In 'Misc' menu change <5.4.t1> parameter setting to 'no' value.
During switching on, message 'LH' is displayed	Weighing pan loaded during switching on	Unload the weighing pan. Zero indication is displayed.

24. ERROR MESSAGES

- Err2** - Value beyond zero range.
- Err3** - Value beyond tare range.
- Err4** - Adjustment weight or start mass out of range ($\pm 1\%$ for adjustment weight, ± 10 for start mass).
- Err5** - Single part mass value is lower than reading unit value.
- Err8** - Tarring / zeroing / start mass determination / adjustment operation time exceeded.
- null** - Zero value from converter.
- FULL2** - Weighing range exceeded.
- LH** - Start mass error, indication out of range (-5% – +15% of start mass).
- 5–FULL** - Limited screen capacity, display of full indication value for totalizing function is impossible.

Caution:

1. Errors: You are informed about display of **Err2**, **Err3**, **Err4**, **Err5**, **Err8**, **null** errors by short sound signal (1 second).
2. You are informed about display of **FULL2** error by continuous sound signal lasting as long as excess load remains on the weighing pan.

25. ADDITIONAL EQUIPMENT

Accessories:

- **P0108** - computer cable
- **P0151** - EPSON printer cable
- **K0047** - 12V DC cigarette lighter cable
- **EPSON** - thermal printer
- **EPSON** - dot matrix printer
- **AP2-1** - power loop output
- **KR-01** - RS232/RS485 converter
- **KR-04-1** - RS232/Ethernet converter
- **SAL/STONE/H** - anti-vibration stainless table
- **SAL/STONE/C** - anti-vibration painted table
- Mass standards with accessories.

Computer software:

- Scale Editor
- RAD-KEY
- PW-WIN



RADWAG BALANCES AND SCALES
ADVANCED WEIGHING TECHNOLOGIES

